

SERVICE BULLETIN

No.205

PRODUCT: Filters

Date: August 24, 1999

SUBJECT: LHA and Gresen Filters, and adapters, sold after August 1996.

EQUIPMENT AFFECTED: Mobile

CLASSIFICATION: Mandatory Safety
Mandatory Repair
Optional Repair
Fix-as-fail
Information



Gresen Filter & Housing

SITUATION: Gresen and LHA filters are interchangeable with Gresen and LHA filter housings. The LHA filter on a Gresen housing is compatible, but the Gresen filter on an LHA housing will leak.



LHA Filter & Housing

SOLUTION: Every Gresen or LHA replacement filter ordered from BTI comes with an extra lip seal (part no. 1007381). Use this seal whenever a Gresen filter is installed on an LHA housing (Note: the LHA housing can be identified by its LHA logo on the top). The seal can be discarded if you are using an LHA filter on a Gresen housing.

Installing a Gresen filter on an LHA housing.

- 1) Remove the old seal from the LHA housing
- 2) Clean the housing groove with a rag
- 3) Install the lip seal with the lip into the groove
- 4) Apply clean oil on the seal
- 5) Install the filter hand tight

Either make of replacement filter can be installed on the Gresen adapter and using the original seal.



Installing the lip seal with the lip first into the LHA filter housing groove.